



Installation Instructions and  
Instructions for Continued Airworthiness  
Kit: LE-PMCF

AIRPLANE MAKE	AIRPLANE MODEL	ENGINE	T.C. No.	CERT. BASIS
Textron Aviation Inc.	180	Continental O-470-A, O-470-J or O-470-K	5A6	CAR 3
	180A	Continental O-470-K		
	180A	Continental O-470-K		
	180B	Continental O-470-K		
	180C	Continental O-470-L or O-470-R		
	180D	Continental O-470-L or O-470-R		
	180E	Continental O-470-L or O-470-R		
	180F	Continental O-470-L or O-470-R		
	180G	Continental O-470-L or O-470-R		
	180H	Continental O-470-L or O-470-R		
	180J	Continental O-470-R, S/N 18052285 through 18052500 and Continental O-470-S, S/N 18052501 and up (see Note 5 TCDS)		
180K	Continental O-470-U			
Textron Aviation Inc.	182	Continental O-470-L	3A13	CAR 3
	182A	Continental O-470-L		
	182B	Continental O-470-L		
	182C	Continental O-470-L		
	182D	Continental O-470-L		
	182E	Continental O-470-L or O-470-R		
	182F	Continental O-470-L or O-470-R		
	182G	Continental O-470-L or O-470-R		
	182H	Continental O-470-R		
	182J	Continental O-470-R		
	182K	Continental O-470-R		



Installation Instructions and  
Instructions for Continued Airworthiness  
Kit: LE-PMCF

AIRPLANE MAKE	AIRPLANE MODEL	ENGINE	T.C. No.	CERT. BASIS
	182L 182M	Continental O-470-R Continental O-470-R		
	182N	Continental O-470-R or Continental O-470-S (See NOTE 4, TCDS)		
	182P	Continental O-470-R, Aircraft S/N 18260826 through 18263475 Continental O-470-S, Aircraft S/N 18260826 and up (See NOTE 4 TCDS)		
	182Q	Continental O-470-U		
	182R	Continental O-470-U		
Textron Aviation Inc.	185 185A 185B 185C 185D 185E 185E 185F A185E A185F	Continental IO-470-F Continental IO-470-F Continental IO-470-F Continental IO-470-F Continental IO-470-F Continental IO-470-F Continental IO-470-F Continental IO-520-D Continental IO-520-D Continental IO-520-D	3A24	CAR 3